

PASSAP®**Electronic-6000****Erreur 207**

L'affichage du message d'erreur "207" (position de début) sans signal sonore indique que le fusible qui se trouve dans l'unité électronique est défectueux. La cause du fusible défectueux est le circuit imprimé défectueux du chariot avant. Une autre unité électronique ne doit en aucun cas être branchée à ce chariot, car le fusible de cette unité électronique serait également grillé. Le circuit imprimé du chariot avant doit être remplacé avant de remplacer le fusible de l'unité électronique.

Fehler 207

Die Fehleranzeige "207" (Startposition) sowie das Ausbleiben des Piepstones zeigt an, dass die Sicherung in der Electronic-Box defekt ist. Die Ursache für die durchgebrannte Sicherung liegt dann jedoch beim defekten Schloss-print. Es darf auf keinen Fall eine zweite Electronic-Box mit diesem Schloss kombiniert werden, sonst wird, auch die Sicherung diese Electronic-Box zerstört. Es muss zuerst der Schlossprint ersetzt werden und danach die Sicherung in der Electronic-Box.

Error 207

The error display "207" (start position) as well as the missing beep tone indicate that the fuse in the electronic box is defective. The cause for the burned off fuse is the defective printed circuit of the front cam-box. Another electronic box must not be connected to this cam-box, otherwise, the fuse of this electronic box is also destroyed. The printed circuit of the front cam-box must be replaced before the replacement of the fuse in the electronic box.